

TURBOCOTE COUCH

Hardwearing Couch, perfect for large scale Aussie turf projects.

Couch 100%



For a resilient, low maintenance lawn, this economical and reliable warm season grass thrives in the summer heat and has excellent drought tolerance. Its low creeping growth habit allows it to self repair patches and wear spots, making it a great choice for high traffic areas and large scale projects on a budget.



Ideal Sowing Times:	
Northern NSW, QLD, Northern WA	Early Spring / Summer/ Early Autumn
NSW, WA, SA	Mid Spring / Summer / Early Autumn
Victoria	Late Spring (Late October/ Early November) / Summer / Early Autumn
FNQ, Northern Territory	Spring / Summer / Autumn
Tasmania	Not recommended.
This grass needs warm soil temperatures to germinate	

This grass needs warm soil temperatures to germinate. Additional irrigation needed for Summer sowing.







New Sowing: 1kg per 100m². Oversowing: Use half sowing rate.

Lawn Sowing Instructions:

PREPARE YOUR SOIL

Clear the area of weeds and debris. Improve drainage by digging or aerating. Level the ground. If the soil is poor quality bring in lawn soil (sandy loam) from a local soil supplier.

FERTILISE

Apply starter fertiliser to the soil (up to 48 hours before or same day as sowing) and water it in. Use Landscape Range KickStart Fertiliser at a rate of 3kg per 100m². Water well.

SPREAD SEED EVENLY

Use the sowing recommended on the pack. Dividing the area and the seed into the same number of parts will help you spread them evenly. Gently rake to ensure good seed to soil contact.

WATERING

For the best outcome. maintain a consistently damp seedbed for 3 to 4 weeks using a fine spray to prevent seed movement. Avoid letting it dry out as germination will slow.

Lawn Maintenance Guide:



Fertilise twice in Autumn and twice in **Spring**



First mow: When well established at around 40-50mm height. Take off only the tips for the first few mows.

When fully established mow regularly and avoid removing more than one-third of the leaf at a time.



Avoid mowing during the heat of the day in summer to prevent stressing your lawn.

